

Assembly Instruction



1. Please prepare headboard, footboard and 2 side rails according to the above picture, use allen wrench to fix hardware in both ends of the side rails.

2. Put the bed slats on. There is a slat with holes in each end. It is to be used in the middle.

3. Use a screw driver (power tool recommended) to fix the slat in the middle onto the side rails. It is designed to prevent the side rails change curved under force.

Any further enquires, change, return, warranty and after sales service terms, please visit www.ifurniture.com