



# ASSEMBLY INSTRUCTION




## ASSEMBLY INSTRUCTIONS

Step 1




## PARTS AND HARDWARE

Note: Individual parts are not shown to scale.




Step 2






# OPERATING YOUR UNIT


Step 3



Step 4



Step 5



Step 6

