



Assembly for MLM-504280



— . Components:


1) Hardware 1set



2) Seat frame (Seat frame with metal slats)



3) Armrest 1set (LHF 1pc + RHF 1pc)



4) Back frame 1pc





5) Seat mattress 2pcs



6) Pillows 2pcs





二、Steps to Assembly



1) Set up the "Seat frame" with "armrests"

Use hardware part A-B-C each 4pcs, through side of seat metal frame there are 4 holes(Extension the slats to make sure have space to set up), attach armrest with seat side(Make sure holes of each are matching), Tighten the bolt part A by hardware part D.



2) Set up the "back frame" with "seat frame"





There are 2 holes at back corner of seat frame, attach backframe into the seat frame(No screws needed).



3) Set up the "Seat mattress" and "Pillows"

Just put the seat mattress onto the seat frame
(No need Screws)



Then this is end the assembly.

How to use the pullout bed?

First take out the seat mattress, pull out the seat frame(Extention it), then put mattress on.

